

---

# S10 Switch Controller- WS01

Instruction Manual



---

## DESCRIPTION

The S10 Switch Controller is designed to switch any 240 Vac appliance rated to 10 Amps 2400 watts on and off from the spa-side via a Water Switch.

---

## INSTRUCTIONS

The Water Switch [purchased separately] has two separate control switches within the one housing.

Plug one side of the Water Switch [white & blue or red & black wires] to the controller. Press the side of the switch to turn on or off the connected appliance.

If two S10 Switch Controllers are being used with a single Water Switch. One side of the switch will operate one S10 Switch Controller, while the opposite side of the switch will operate the second S10 Switch Controller.

Your S10 Switch Controller is now ready to use.

---

---

## WARRANTY – WS01

This range of product is covered by a limited 3 year warranty against component failure or faulty workmanship from the date of installation. A faulty unit should be returned in the first instance to the dealer from which the unit was purchased.

Damage to the unit due to misuse, power surges, lightning strikes or installation that is not in accordance with the manufacturer's instruction may void the warranty.

Warranty does not cover travel costs to or from installation site.

If the power cord is damaged, do not use the controller; return the unit to the supplier for repair.

### CUSTOMER RECORD [To be retained by the customer]

DEALER/INSTALLER NAME

---

SERIAL NUMBER

---

DATE INSTALLED

---

For service assistance phone 1300 130 693



#### **Dontek Electronics Pty Ltd**

PO Box 239, Bayswater VIC 3153 Australia

Phone: +613 9762 8800 Email: sales@dontek.com.au