
E10 Digital Switch Controller- WS02

Instruction Manual



DESCRIPTION

The E10 Digital Switch Controller is designed to switch any 240 Vac appliance rated to 10 Amps 2400 watts on and off from the spa-side via a Water Switch. It also incorporates a “Time Out” function that can be set for automatically turning the connected appliance off after a pre-set time of 10, 20 or 30 minutes.

INSTRUCTIONS

The Water Switch [purchased separately] has two separate control switches within the one housing. For control of an appliance, press either side of the switch.

If two E10 Digital Switch Controllers are being used with a single Water Switch. One side of the switch will operate one controller, while the opposite side of the switch will operate the second controller.

Setting the "Time Out" function.

To set the "Time Out" function, firstly ***UNPLUG THE CONTROL BOX FROM THE MAINS POWER SUPPLY.*** Open the E10 Digital Switch Control box. On the inside of the lid, there is Blue "Dip" Switch labelled "A". By adjusting the two switches you can adjust the Run Time setting to either "Off", 10 minutes, 20 minutes or 30 minutes". Once set, refit the lid ensuring the ribbon cable is connected to both the lid and the main circuit board. Reconnect the controller to the mains power supply. Ensure your switch is plugged into the Green Socket and your appliance is plugged into the Power Outlet on the E10 Digital Switch Control Box.

Your controller is now ready to use.

WARRANTY – WS02

This range of product is covered by a limited 3 year warranty against component failure or faulty workmanship from the date of installation. A faulty unit should be returned in the first instance to the dealer from which the unit was purchased.

Damage to the unit due to misuse, power surges, lightning strikes or installation that is not in accordance with the manufacturer's instruction may void the warranty.

Warranty does not cover travel costs to or from installation site.

If the power cord is damaged, do not use the controller; return the unit to the supplier for repair.

CUSTOMER RECORD [To be retained by the customer]

DEALER/INSTALLER NAME

SERIAL NUMBER

DATE INSTALLED

For service assistance phone 1300 130 693



Dontek Electronics Pty Ltd

PO Box 239, Bayswater VIC 3153 Australia

Phone: +613 9762 8800 Email: sales@dontek.com.au