# 240V Switch Box-SB05

Instruction Manual





## **DESCRIPTION**

The SB05 is designed to switch an internal relay to the closed position when the box is powered by its 240Vac power connection. When 240Vac is removed from the SB05 then the relay contact will open. The SB05 can be used to activate other products from a 240V switched source.

SB05 Instructions 1

## **INSTALLATION INSTRUCTIONS**

#### **CONTROLLER MOUNTING**

Find a suitable location to mount the control box. The controller must be installed out of direct weather and no closer than 3 meters from the water's edge. Lift up the two mounting tabs and use two appropriate screws to mount the control box to the wall, keeping in mind that the power cable is 1.8m long and should be plugged directly into a general power outlet, not into an extension lead.

#### **CONTROLLER WIRING**

The 2 pin connector at the bottom connects to the internal switch. Wire the 2 pins to the device that requires an open/close connection

#### **INSTRUCTIONS**

When the SB05 is powered, the contacts close. When power is removed, the contacts open.

SB05 Instructions 2

#### **WARRANTY - SB05**

This range of product is covered by a limited 3 year warranty against component failure or faulty workmanship from the date of installation. A faulty unit should be returned in the first instance to the dealer from which the unit was purchased.

Damage to the unit due to misuse, power surges, lightning strikes or installation that is not in accordance with the manufacturer's instruction may void the warranty.

Warranty does not cover travel costs to or from installation site.

If the power cord is damaged, do not use the controller; return the unit to the supplier for repair.

## **CUSTOMER RECORD** (To be retained by the customer)

DEALER/INSTALLER NAME

SERIAL NUMBER

DATE INSTALLED

For service assistance phone 1300 130 693



# **Dontek Electronics Pty Ltd**

PO Box 239, Bayswater VIC 3153 Australia

Phone: +613 9762 8800 Email: sales@dontek.com.au

SB05 Instructions 3